

後期ABSコンバージョン必要部品一覧(左ハンドル ACURA用)

Parts List fot conversion Later model ABS System(LHD ACURA)

In order to install the later model ABS system,
Please prepare following parts.

- 57101-S2A-003 RUBBER,ABS,MOUNTING X3
- 57102-S2A-003 BOLT,ABS,MOUNTING X2
- 57116-SL0-000 BRACKET,MODULATOR
- 9407106080 NUT WASHER 6mm X2
- 57110-SL0-Z03 MODULATOR ASSY
- 46210-SL0-003 VALVE,ASSY,PROPORTIONING
- 46215-SL0-000 BRACKET,PROPORTONING,VALVE
- 46372-SL0-D00 PIPE,COMP,S.BRAKE
- 46373-SL0-D00 PIPE,COMPT.BRAKE
- 46374-SL0-D00 PIPE,COMP,U.BRAKE
- 46375-SL0-D00 PIPE,COMP,V.BRAKE
- 46376-SL0-D01 PIPE,COMP,W.BRAKE
- 46377-SL0-D01 PIPE,COMP,X.BRAKE
- 46378-SL0-D00 PIPE,COMP,Y.BRAKE
- 46379-SL0-D01 PIPE,COMP,Z.BRAKE
- 46392-SE0-000 CLIP,BRAKE,PIPE
- 46392-SL0-003 CLIP,D
- 46380-SH3-000 GROMMET,A,BRAKE,PIPE X2
- 957010601605 BOLT,FLANGE 6X16 X3
- 957010804005 BOLT,FLANGE.8X40
- 46396-SL0-003 CLIP,BRAKE,PIPE

